

Failure indication elements for XSz safety valves

Although the XSz safety valves do not require an external electrical monitoring to fulfill the safety function, some applications need to have a visual electrical or acoustic signalling of a malfunction. This can be achieved by failure indication elements mounted on the XSz safety valve.

Pressure switch



Failure indication module



Pressure balance



Description	Model	XSz8	XSz 10	XSz 20	XSz32	XSz 50	XSz 10 V	Notes
Pressure switch	0881400	●	●	●	●	●*	●	Switches every time the valve switches, response time dependent on the valve
Failure indication	1028063	●	●	●	●	●	●	Switches only in case of malfunction
Pressure balance	1028100				●	●		For separately used clutch and brake

* Mounting only possible with flange model 0545005