

- > 5/2-way Port size: G1/4, G1/2, 1/4 NPT & 1/2 NPT
- Inherently fail-safe without residual pressure
- Dynamic self monitoring
- > Fast exhaust capability
- Improves safety and reduces downtime
- XSz safety valves are also available as 3/2 way valves
- > With the appropriate application,

performance level "e" (cat. 4) of DIN EN ISO 13849-1 is achieved for the safety function "Pressure building up from '1' to '2' and pressure dropping from '2' to '3'. DGUV and other approvals

- Suitable for safety applications with double acting cylinders
- > Also available with ,UL-recognized' solenoids [ ] list



# Technical features Medium:

Compressed air, filtered  $\leq 50~\mu\text{m},$  lubricated or non-lubricated

### Suitable oils:

Shell Tellus S2 MA 32, ExxonMobil Febis K 32 or comparable oil with DVI values < 8 (DIN ISO 1817) and ISO viscosity class 32-46 (DIN 51519)

### Type of control:

Electromagnetic pilot operated, with spool

#### Flow:

See page 2

### **Operating Pressure:**

XSz8V:

3,2 ... 10 bar (46 ... 145 psi) XSz10V:

3 ... 10 bar (43 ... 145 psi)

### Mounting position:

Preferably upright with solenoids on top

# Ambient/Media temperature:

XSz8V:

+2 ... +50°C (+35 ... +122°F) XSz10V:

-10 ... +50°C (+14 ... +122°F)

For temperatures higher than +35°C (+95°F) we recommend to use lubricated air.

Air supply must be dry enough to avoid ice formation at temperatures below +2°C (+35°F)

### Monitoring:

Internal

It is advisable to install a failure indication module to display malfunction messages. For further information please refer to data sheet 5.14.420

### Materials:

Body: aluminium Seals: PUR, NBR

### **Technical data**

Symbol		Series	Pressur (bar)	e range (psi)	Port siz 1 (P)	es 2 (A)	3 (R)	4(B)	5 (S)	Weight (kg)	(lbs)	Drawing No.	Model *1) ISO G thread	NPT thread
		XSz 8V	3,2 - 10	46 145	1/4	1/4	1/4	1/4	1/4	1,5	3.3	1	24928503052	24928703052
		XSz 10V	3,0 - 10	43 145	1/2	1/2	3/4	1/2	1/2	2,8	6.1	2	24929823052	24929833052
		XSz 8V *2)	3,2 - 10	46 145	1/4	1/4	1/4	1/4	1/4	1,5	3.3	1	24928503048	24928703048
2 (D) (		XSz 10V *2)	3,0 - 10	43 145	1/2	1/2	3/4	1/2	1/2	2,8	6.1	2	24929823048	24929833048
3 (R) 1 (P)	2 (A)													
5 (S) 4	4 (B)													
1.														

<sup>\*1)</sup> To order please insert voltage requested for each valve. All valves are delivered with silencers. Plugs not supplied, see page 2

### Technical data - solenoids

Model:	3052 and 3048 (UL)
Standard voltages:	24 V d.c. and 230 V a.c., other on request
Duty cycle:	100% ED
Protection class:	IP65
Electrical connection:	DIN EN 175301-803 (DIN 43650), form A & Form B

•	
	<u> </u>
	4
_	

⊕ ⊶

Circuit diagram

Model	Power consumption	Current V a.c.		Connector
	V d.c. (W)	Inrush (VA)	Hold (VA)	
3048	3,7	-	-	Form A
3052	4,8	12	8,5	Form B



<sup>\*2)</sup> with UL-recogniozed solenoid (24 VDC, other voltages on request)



# Flow rate as per ISO 6358 (CETOP RP 84 P) XSz 8V

	Port 1 (P) » 2 (A) (m³/h) *3)	2 (A) » 3 (R) (m³/h) *3)	1 (P) » 4 (B) (m³/h) *3)	4 (B) » 5 (S) (m³/h) *3)
Normal cycle	36	112	35	49
Malfunction I *1)	_	71	32	_
Malfunction II *2)	_	80	26	_

<sup>\*1)</sup> Malfunction I: only solenoid 1 switched

## XSz 10V

	Port 1 (P) » 2 (A) (m³/h) *3)	2 (A) » 3 (R) (m³/h) *3)	1 (P) » 4 (B) (m³/h) *3)	4 (B) » 5 (S) (m³/h) *3)
Normal cycle	150	390	160	98
Malfunction I *1)	_	260	120	_
Malfunction II *2)	_	260	150	_

# Switching times XSz 8V measured with 400 cm<sup>3</sup> consumer

	Ports	Pressure characteristic	•	g time (m solenoid 6 bar	
ON position	1 (P) » 2 (A)	rising	169	147	128
	4 (B) » 5 (S)	falling	159	183	203
OFF position	2 (A) » 3 (R)	falling	111	129	142
	1 (P) » 4 (B)	rising	164	161	140
0FF *1)	2 (A) » 3 (R)	falling	124	145	167
Malfunction I	1 (P) » 4 (B)	rising	192	169	145
0FF *2)	2 (A) » 3 (R)	falling	121	143	164
Malfunction II	1 (P) » 4 (B)	rising	181	156	129

<sup>\*1)</sup> Malfunction I: Solenoid 1 only switched off

# XSz 10V measured with 700 cm<sup>3</sup> consumer

	Ports	Pressure characteristic		ng time (m . solenoid 6 bar	
ON position	1 (P) » 2 (A)	rising	72	69	69
	4 (B) » 5 (S)	falling	113	127	145
OFF position	2 (A) »3 (R)	falling	55	64	70
	1 (P) » 4 (B)	rising	74	85	91
0FF *1)	2 (A) » 3 (R)	falling	70	86	126
Malfunction I	1 (P) » 4 (B)	rising	124	154	201
0FF *2)	2 (A) »3 (R)	falling	70	87	102
Malfunction II	1 (P) » 4 (B)	rising	87	111	129

## **Accessories**

Valve	Connector DIN EN 175301-803	Silencer	Integrated silencer	
Series		The second second		
XSz 8V	0680003 / UL: 0570275	MB002B (G 1/4)	_	
	0680003 / UL: 0570275	MB002A (1/4 NPT)	_	
XSz 10V	0680003 / UL: 0570275	MB004B (G 1/2)	0016422	
	0680003 / UL: 0570275	MB004A (1/2 NPT)	0016422	

Note: The security is dependent on the quality of the silencer, use only original Norgren silencer!

All solenoids are delivered without connectors. If connectors are neccessary, please order them separately.

<sup>\*2)</sup> Malfunction II: only solenoid 2 switched

<sup>\*3)</sup> Nominal flow volume Q nom. at p1 = 6 bar and  $\Delta p$  = 1 bar

<sup>\*2)</sup> Malfunction II: Solenoid 2 only switched off

<sup>\*3)</sup> Operating time: From electric ON signal to 90% nominal pressure build-up From electric OFF signal until pressure drops to 10% of nominal pressure.



The double-acting valve is a system which meets the requirements of Safety Category 4 (self-monitoring control devices), provided that the actuating solenoids are controlled in conformity with Safety Category 4. If the double-acting valve is used in conjunction with an electric two-hand control, the actuating solenoids must be controlled by an output signal from a Type III C electric two-hand control as per DIN EN ISO 13849-1 if Category 4 has been selected as a result of a risk assessment. If the double-acting valve is used to control dangerous movements in an electropneumatic system then the pneumatic control commands used to control the actuating solenoids, the connection lines and any downstream control units must comply with the safety category selected on the basis of a risk assessment.

Owing to its type of construction, the double-acting valve cannot prevent an elevated load from descending slowly in the event of a power failure or the power being disconnected. If a power failure or a disconnection of power can cause a dangerous movement, then additional devices may be required (e.g. spring-loaded clamping devices, pilot-controlled non-return valves) depending on the risk assessment and the safety category selected on the basis of that risk assessment.

The 5/2-way double-acting valve is not suitable for the control of clutch and brake on mechanical presses.

### Description of the 5/2 way valve


Like the 3/2-way safety valve, the 5/2-way safety valve consists of two mechanically separated pilot control systems and main valve systems. The valves are solenoid operated. The design of the main valve system is such that, in rest position, port 2(A) is vented and port 4(B) is pressurised.

The valves are solenoid operated. The design of the valve is such that port 2(A) will only be depressurised and port 4(B) will only be vented if:
a) both command signals arrive at the same time within a time delay <0.1 s (synchronous actuation)

- b) both spindles were previously in rest position
- c) both spindles move into swithing position within the given time delay.

#### Failure:

In the event of a fault on one of the two systems (e.g. mechanical blockage), the pressure will fail to build up on port 2 (A) and port 4 (B) will remain pressurised upon restart (provided that the operating pressure is present on port 1 (P)).



# Solenoids de-energized

Port 2 (A) is vented via port 3 (R). Port 4 (B) is connected to pressure port 1 (P).

# Solenoids energized

The solenoids are energized simultaneously. Process port 2 (A) is connected to pressureport 1 (P). Port 4 (B) is vented via exhaust port5 (S). Each valve system is self-monitoring and checks for correct functioning upon each switching operation (dynamic monitoring).

# Malfunction

The solenoids are energized non simultaneously. The dynamic monitoring system detects the time delay in actuation and prevents pressure from building up on process port 2 (A). Port 4 (B) remains connected to 1 (P) port so as to prevent, for example, the upper tool of the press from descending.







## XSz 8V - with silencer










		102	_1
	42	80	
9	212=/		28,5

Model	1 (P), 2 (A), 3 (R), 4 (B), 5 (S)
24928503052 /3048	G1/4
24928703052 /3048	1/4 - 18 NPT

# (2)

## XSz 10V - with silencer



 $<sup>\</sup>ensuremath{\underline{\sf 1}}$  Mounting interface for pressure switch and failure indication module.

<sup>\*</sup> sealed with plug



For external indication (e.g. visual, electrical or acoustic signal) of a malfunction, the installation of a failure indication element is recommended. Such an element is not necessary to fulfil the safetyfunction of the valve. (For further information please see the corresponding data sheet no. 5.14.420)

A suitable air treatment unit (dehydration, filtration, lubrication) must be connected upstream of pressure port 1 (P). Lubrication can only be omitted if the connected consuming device and all additional equipment is suited for oil-free operation. Degree of filtration: 50 µm. The lubrication should be adjusted to supply only enough oil to form a film on the valve spool and bore. Excessive lubrication may cause a build-up of oil in the pilot lines and cause sluggish operation of the valves.

The size of pressure regulator, lubricator and filter must be consistent with the inlet port size. An accumulator tank is recommended between the pressure regulator and safety valve. The operating pressure must not drop below the minimum operating pressure indicated on the name plate and the use of a pressure switch is suggested.

Attention: Uncontrollable elements, such as quick exhaust valves, nozzles and non-return valves may not be installed between the press safety valve and clutch brake.

It is the responsibility of the purchaser and/or installer of the Norgren safety valves to make sure that the valve and all other components comply with all relevant national regulations and the specifications of the local safety associations.

The valves should be checked at intervals depending on the loads to which they are subjected, at least, however, once a year. The relevant tests must be carried out according to the corresponding operation and maintenance instructions of the unit and the local safety regulations. In case of malfunctions the unit has to be tested and/or replaced immediately. Repairs and maintenance must only be carried out by the after-sales service of the valve manufacturer or by a qualified engineer trained by the valve manufacturer.

Important for use at presses:

The combination with the electrical press control must meet the DIN EN ISO 13849-1 requirements.

All liability is denied for unauthorised modification of the units, installation or usage not in accordance with the manual, the local safety requirements and the principles of DIN EN ISO 13849-1.

These products are intended for use in industrial compressed air systems only. Do not use these products where pressures and temperatures can exceed those listed under

### »Technical features/data«.

Before using these products with fluids other than those specified, for non-industrial applications, life-support systems or other applications not within published specifications, consult IMI Precision Engineering, Norgren GmbH

Through misuse, age, or malfunction, components used in fluid power systems can fail in various modes.

The system designer is warned to consider the failure modes of all component parts used in fluid power systems and to provide adequate safeguards to prevent personal injury or damage to equipment in the event of such failure.

System designers must provide a warning to end users in the system instructional manual if protection against a failure mode cannot be adequately provided.

System designers and end users are cautioned to review specific warnings found in instruction sheets packed and shipped with these products.